

## TWO COMPONENT SYSTEMS

On top of new substrate or completely sanded.

		FIBRE GLASS	ALUMINIUM	WOOD	STEEL
1	Cleaning	High pressure fresh water washing and degrease with BoatWash if necessary			
2	Preparation	Dry sand with P120-150 grade	Dry sand with P120-150 grade	Dry sand with P80 - P150 grade	Grind
3	Apply	AntiPest, XPrimer		Clipper I (5-15 coats wet-on-wet until total absorption)	Epoxy Yacht HB
4	Apply	AntiPest, XPrimer			
5	Apply	2 x TopGloss, 2 x Xtreme Gloss			

1. One thick coat with primer may be accepted but be aware that this may result in an uneven surface, affecting the final finish.